

FENDER "PRO-AMP" SCHEMATIC

MODEL 5E5

NOTICE

VOLTAGES READ TO GROUND
WITH ELECTRONIC VOLTMETER.
VALUES SHOWN \pm OR $- 20\%$

